

Download and install the **Tellur Smart App** for either iOS or Android devices.







Once downloaded, the app will ask you to register your device. Enter your phone number or email which makes you feel comfortable and select the country you live in.

If phone number selected you will receive a text with a registration code. If you choose email you will then create a password.


Input the Registration Code you received via text if phone method has been used or create password if email method chosen.



2 3

Adding a New Device

- Turn on power of device being paired and make sure light is flashing quickly.
- Open App and Click "+" to add appropriate device.
- Select WiFi network and input password of WiFi then.
- Once connected the App will prompt the connection, then you can rename the device or just click "done".





• Once App is installed on your device and you have added your smart device to your app you will be able to control it.


4 5

Next step is to sync with Alexa or echo:

- 1.Go to Home menu on Alexa App
- 2.Select "Skills" in home menu of Amazon Alexa




3. Type [Smart Life] on search window and find




4 5

4. Click on the App [Smart Life] and press Enable to activate "smart life".




5. Then you need to input your account and password that you registered in Tellur Smart . Now you finish the Alexa Link.



6. Your [Brightfun] App has been skilled with Alexa, and now you can control any device added to your Tellur Smart App, remember that if you rename the device you added, it must be a simple name that Alexa can recognize.

7. Control your smart devices through Alexa Now you can control your smart devices through Alexa. Take bedroom light as the example, the supported voice commands are as below:

"Alexa, turn off bedroom light"
"Alexa, turn on bedroom light"
"Alexa, dim bedroom light"
"Alexa, set bedroom light to red"

6 7

Why failed to add device?

1. Please check whether device is powered on;
2. Whether phone is connected via Wi-Fi;
3. Whether device is ready for configuration.

To get the device ready before configuration, normally you can manually press on the device to get it ready. Please refer to "Product Instructions" or Device Reset Instruction for details.

Notice Each time to add device, reset Wi-Fi to get device ready for configuration and make sure router is working properly.

4. Check routers or related: If router is dual-band router, select 2.4G network and add device. You also need to enable router's broadcasting function. Set up wireless router: Set encryption method as WPA2-PSK and authorization type as AES, or set both as auto.

Wireless mode cannot be 11n only. Don't use Chinese to name router Wi-Fi.To stay strong Wi-Fi signal, please keep device and router within certain distance.

Whether connected devices have reached the maximum number of router's connections. If so, please try by turning off the Wi-Fi connection of some device. Router's wireless MAC filtering function is enabled. Remove the device from the filter list and make sure that router is not prohibiting device from connection.

5. Make sure the password entered in App is correct when adding new device

6 7

EZ and AP connection modes:

Smart devices can be connected using two modes: EZ and AP.

EZ represents the easiest way of connecting and enabling a smart device. You will need to have the device, active wireless network through with login password and Tellur Smart APP installed on a smartphone / tablet.

AP mode can be used to configure and enable a smart device first with the smartphone / tablet and later on to the Wi-Fi network.

How to reset device?

1. Reset heater, oil heater etc. Long press reset button for 5 seconds until indicator light flashes, representing successful reset; Indicator light quickly flashes (2 times per second), representing quick connect mode;
- Indicator light slowly flashes (one time per 3 seconds), representing AP mode; Under EZ mode, long press reset button for 5 seconds until indicator light slowly flashes, representing switching to AP mode and vise versa.
2. Reset smart light•Turn off light first. Switch lightwith the steps: Switch on-off-on-off-on (time interval cannot exceed 10 seconds), flashing lights represents successful reset; if no light flashes, please repeat the steps above;
- Quick light flashes (4 times per second), represent EZ mode; Slow light flashes (2 times per 3 seconds) represent AP mode; Under EZ mode, turn off lights and then switch light with the steps: Switch on - off - on - off - on (time interval cannot exceed 10 seconds). Light begins to slowly flash, representing that it has switched to AP mode and vise versa.

6 7

How to add device under EZ mode?

1. Make sure that indicator light or light quickly flash;
2. Phone has connected to Wi-Fi router and been able to connect to Internet;
3. Tap "Add device" in app and enter correct Wi-Fi pass-word. Touch to search device around;
4. In the device list, select and add the device.

How to add device under AP mode?

1. Make sure that indicator light quickly flashes or light slowly flashes;
2. Tap "Add device" in App and then "AP mode" in the top right corner. Connect to device hotspot first and then Wi-Fi.
3. Tap "Next" to add device.

Can I control device with 2G/3G/4G network?

When adding device for the first time, it requires that device and phone need to be under the same Wi-Fi environment. After successfully adding device, you can remote control device with 2G/3G/4G network

How can I share my device with family?

Open App, go to "Profile" > "Device Sharing" > "Sharings Sent", tap "Add Sharing", then you can share the device with the added family members.

How can I manage the devices shared by others?

Open App, go to "Profile" > "Device Sharing" > "Sharings Received", then you can find the devices shared by other users. It also allows to add remarks to users or delete certain sharings by long pressing or swiping left.

8 9


Quick Guide of Using Google Home to Control Smart Devices

1. What you need to get started Before using Google Home to control your devices, you must meet the following conditions.
 - A Google Home device, or Android phone with Google Assistant.
 - Latest Google Home app.
 - Latest Google app (Android only)
 - A Google account.
 - The device display language must be set to English US.
 - brightfun app and a related account.
 - Smart devices.

Add devices in Tellur Smart App (Refer to App Instruction)

You can skip this part if you've already add some devices to your Tellur Smart account, and in the meantime the devices' name are easily recognized.

1. Download Tellur Smart App You can scan the QR code below to download the Tellur Smart App:



You can also search Tellur Smart App in either App Store or Google Play to install the app.

8 9

2. Register a Tellur Smart account and sign in the app (Refer to App Instruction)

Open the Tellur Smart app, tap "Register" to register an account, then sign in the app.

3. Add device and change device's name (Refer to App Instruction)

Sign in with the Tellur Smart account, add the device, then change device name to a easily recognized word or phrase, like "bedroom light".

Link account in Home Control

1. Tap "Home Control" in the hamburger menu on the Google Home app's home page, then tap "+".



2. Find in the list. In the new window, select your Smart Life account's region, type your Tellur Smart account and password, then tap "Link Now". After you assign rooms for devices, your devices will be listed in the Home Control page.

10 11

Declaration of conformity

We, ABN SYSTEMS INTERNATIONAL S.R.L., Bucharest, Sector 1, Marinariilor street, nr. 31, we declare on own responsibility that the product below:

Product description	Brand	Product code
WiFi Smart Bulb E27, 2400W, 10A	Tellur	TLL331001
WiFi Smart Bulb E27, 10W, white/warm, dimmer	Tellur	TLL331011

It does not endanger life, health, work safety, does not have a negative impact on the environment and corresponds to the standards stated in the manufacturer's declaration of conformity.

The product is in compliance with the following standards and / or other normative documents:

RED – 2014/53/EU
Applied standards:
EN 62479 (Health)
EN 60950-1 (Safety)
EN 301 489-1/-17 (EMC)
EN 300 328 (Radio)
RoHS – 2011/65/EU

The product bears CE mark, applied in 2018

Name: George Barbu Place and date:
Function: General manager Bucharest, 02-05-2018
Signed:



10 11

Declaration of conformity

We, ABN SYSTEMS INTERNATIONAL S.R.L., Bucharest, Sector 1, Marinariilor street, nr. 31, we declare on own responsibility that the product below:

Product description	Brand	Product code
WiFi AC Plug, USB 1A, 2400W, 10A	Tellur	TLL331021
WiFi Power Strip, 3 Outlets, 4*USB 4A, 2200W, 10A, 1.8m	Tellur	TLL331031
WiFi switch, 1 port, 1800W, 10A	Tellur	TLL331041
WiFi switch, 2 ports, 1800W, 10A	Tellur	TLL331051

It does not endanger life, health, work safety, does not have a negative impact on the environment and corresponds to the standards stated in the manufacturer's declaration of conformity.

The product is in compliance with the following standards and / or other normative documents:

RED – 2014/53/EU
Applied standards:
EN 60950-1:2006+A2:2013 (Safety)
EN 62311:2008
EN 301 489-1 V2.2.0 [2017-03] (EMC)
EN 301 489-17 V3.2.0 [2017-03]
EN 300 328 V2.1.1 [2016-11] (Radio)
RoHS – 2011/65/EU

The product bears CE mark, applied in 2018

Name: George Barbu
Function: General manager



10 11

Disposal and recycling information

The crossed-out wheeled-bin symbol on your product, battery, literature or packaging reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the normal waste stream with household garbage. It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of waste electrical and electronic equipment (WEEE) and batteries according to local laws. Proper collection and recycling of your equipment helps ensure EEE waste is recycled in a manner that conserves valuable materials and protects human health and the environment, and/or improper recycling at the end of its life may be harmful for health and environment.

CE FC ♻️

10 11

Vielen Dank, dass du dich für uns entschieden hast! Lade die Tellur Smart Applikation auf deinem Smartphone herunter und folge folgende Installationsschritte.
Die Tellur Smart Applikation kann an **Amazon Alexa** oder **Google Home**

in the
store



- Stelle sicher, dass das du verbinden eingeschaltet ist
- Öffne die Applikation wähle „+“ aus, um hinzuzufügen.
- Wähle das WiFi aus und gebe das

ndung kannst
ennen und
em du die
e drückst

A screenshot of the Windows taskbar. The Start button is on the left. In the center, there are several taskbar icons: a folder, a web browser, and a file explorer. On the right, the system tray contains the volume icon, network icon, and a clock showing 10:10 AM on 10/10/10.

Z.B:
 "Alexa, turn off bed room light"
 "Alexa, turn on bed room light"
 "Alexa, dim down bed room light"
 "Alexa, set bed room light to red"

stellen Sie sicher, dass das in die Applikation
gegebene Passwort richtig ist, wenn Sie ein neues
tät hinzufügen.

Das schnelle Leuchten (4 Mal/Sekunde) lässt sich das Gerät in dem EZ-Modus Das langsame Leuchten (2 Mal/ 3 s) gibt an, dass sich das Gerät in dem AP-Modus befindet. In dem EZ-Modus folgen Sie die Taste ON-OFF-ON-OFF-ON (in schneller Folge, ein Intervall kürzer als 10 Sekunden), um das Gerät in den AP-Modus umzuschalten.

Das Gerät und das Telefon an
-Router angeschlossen ist. Nach
dem Hinzufügen des Gerätes können
mit der 2G/3G/4G Verbindung steuern.



2. Suche in der Liste. In das neu geöffnete

- Ok Google, stelle das um.

Wohnzimmer in Rot | Das Produkt
und/oder
RED - 20

richt folgenden Standards
Richtlinien:

Das Produkt entspricht folgenden Standards

Materialien und Komponente
Produktes benutzt wurde
Materialien, die wiederben
können.

... sind hochwertige
... und recycelt werden

en lokalen Behörden für
ungszentren, die von den
beteiligten für die
htet sind.

CE FCC

CE FCC ♻

