









Wireless keyboard, Mini TLL491241-TLL491251

-  Installation guide and operation instructions
-  Ghid de instalare și instrucțiuni de funcționare
-  Guía de instalación e instrucciones de funcionamiento
-  Guide d'installation et mode d'emploi
-  Guida all'installazione e istruzioni per l'uso
-  Einbauanleitung und Bedienungsanleitung

A silhouette of a city skyline with various skyscrapers of different heights and shapes, set against a dark background.

INTO YOUR FUTURE

Thank you for choosing Tellur products!

To ensure an optimum performance and safety, please read this user manual carefully before using the product. Keep this user manual safe for future references.

TECHNICAL SPECIFICATIONS

Connectivity: Wireless, Nano receiver USB

Layout: US, 84 keys

Wireless range: Up to 10 meters

Compatible systems: Windows, MAC

Available colors: White & Black

Product dimensions: 315mm x 122mm x 29mm

Product weight: 327 gr

Package includes:

1 x Wireless keyboard, 2.4Ghz

1 x AAA battery

Connection:

1. To turn on the keyboard, switch the power button located at the top of the keyboard.
2. With a Plug and play installation system, the keyboard does not require any additional driver to work.
3. Remove the nano receiver from the back of the keyboard and insert it into your computer's USB port.
4. The keyboard will automatically connect with your computer.

FN + Switch for Windows

***Windows version: 10 or more**

FN + F1 = Music

FN + F7 = Play/Pause

FN + F2 = Volume -

FN + F8 = Stop

FN + F3 = Volume +

FN + F9 = Internet

FN + F4 = Volum mute

FN + F10 = Email

FN + F5 = Previous track

FN + F11 = My computer

FN + F6 = Next track

FN + F12 = Favorites

Disposal and recycling information



The crossed-out wheeled-bin symbol on your product, battery, literature, or packaging reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the normal waste stream with household garbage.

It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of waste electrical and electronic equipment (WEEE) and batteries according to local laws. Proper collection and recycling of your equipment helps ensure EEE waste is recycled in a manner that conserves valuable materials and protects human health and the environment, improper handling, accidental breakage, damage, and/or improper recycling at the end of its life may be harmful for health and environment.